CSICOL Version 8

Standalone Installation Instructions

IMPORTANT: READ BEFORE INSTALLATION

TO ENSURE PROPER INSTALLATION, FOLLOW STEPS CLOSELY

This software is protected by a license manager system. To use this software, a License File must be present. The License File is locked to a specific computer or to a Computer ID Key (Hardware Device or Dongle). The Software can be installed either on a single computer (i.e., "Standalone") or on a Network Server. If it is installed on a Network Server, the license file determines how many users are supported.

▶▶ If you have previously installed CSICOL version 8, make a backup copy of the permanent license file "lservrc" before proceeding with this installation.

▶ To Install the Program

1. Insert the CD into the CD drive and follow the installation instructions.
2. When asked to do so, enter the serial number found on the CSICOL CD jewel case.

A 30-day temporary license file is included with the package for new users.

Existing users should copy the saved permanent license file "lservrc" over the temporary one and skip the next step.

▶ To Obtain a Permanent License File

Locked to a Computer:

1. Go to the installation directory and double click on **"echoid.exe"**
2. Copy the code number in the window to the locking Code field at the bottom of Request For License Form.

Locked to a Computer ID Key:

1. You do not need to fill in the Locking Code number

Fax the completed Request for License Form to CSI

A license file will be emailed to you.

Copy that license file into the installation directory.

Computers and Structures, Inc.
1995 University Ave. Suite 540
Berkeley, CA 94704
Phone 510-845-2177
Fax 510-845-4096
www.csiberkeley.com

CSICOL Version 8

Network Installation Instructions

IMPORTANT: READ BEFORE INSTALLATION

TO ENSURE PROPER INSTALLATION, FOLLOW STEPS CLOSELY

This software is protected by a license manager system. To use this software, a License File must be present. The License File is locked to a specific computer or to a Computer ID Key (Hardware Device or Dongle). The Software can be installed either on a single computer (i.e., "Standalone") or on a Network Server. If it is installed on a Network Server, the license file determines how many users are supported.

A. Install the CSICOL Software

1. On the server, insert the CD into the CD drive, go to the Installation page and click on the Network button. When asked to do so, enter the serial number found on the CSICOL CD jewel case. (Note that this installation is for file sharing only and not for running the program. If you want to run CSICOL on this computer you would also need to do a Workstation installation per step C .)

B. Install the License Manager Software

1. The communications protocol for the network must be TCP/IP or Netware IPX/SPX.

2. The CD contains the License Manager program SentinelLM 7.2.0.23. If you are currently running an earlier version of SentinelLM then it should be uninstalled prior to installing this version. Note that all commuter licenses should be checked in before uninstalling the old version.
   Click on the License Manager button on the CD and follow the instructions to install SentinelLM 7.2.0.23. (Note that you can install this software on any Windows NT/2000/XP computer on your network, it does not have to be installed on a server.) If you have uninstalled an earlier version of SentinelLM you must copy your license file "lservrc" to the newly created folder and run "loadls.exe" to Remove and then Add the service. This will register your "lservrc" file with the new version of SentinelLM.

3. A 30-day temporary license for one user is included with the package. To register the temporary license, double click on **"lsLicense.bat "** located in the CSICOL Server\License Manager" folder which was installed in step A.

4. For more detailed information about the License Manager or the License Manager Administration program **"WlmAdmin"**, see the *License Manager System Administrator's Guide.*

C. Install the Workstation Software

1. Run **"Setup.exe"** located in the CSICOL Server" folder on the server from each workstation. This will copy support files to the workstation and set up a link to CSICOL on the server.

2. Alternatively, you can run the Standalone installation on each workstation and have all the CSICOL files installed locally. To do this, insert the CD into the CD drive, go to the Installation page and click on the Standalone button. When asked to do so, enter the serial number found on the CSICOL CD jewel case.

3. If CSICOL is slow in locating the license, (or can't find it), set the **System** Environment Variable LSFORCEHOST on the workstation to the host name of the computer running the License Manager software. Reboot the workstation for the Environment Variable to take effect. Refer to the *License Manager System Administrator's Guide* if you need help on setting this variable.

D. To Obtain a Permanent License File

Locked to a Computer:
Run **"echoid.exe"** on the computer running the License Manager software. Copy the code number from the window that appears to the Locking Code field at the bottom of the Request for License Form. (You might need to copy **"echoid.exe"** to that computer first) . **"echoid.exe"** is located on the CSICOL Server computer in the CSICOL Server\License Manager" folder.

Locked to a Computer ID Key:
Complete the Request for License Form. You do not need to fill in the Locking Code number.

Fax the completed Request for License Form to CSI. A license file and instructions will be emailed to you.